

# LANTERN SPARK IGNITER

829A705T




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5

**CAUTION:** Follow lantern lighting instructions and warnings when using this product. Do not operate lantern when there is a hole in mantle(s). A hole can cause lantern to overheat and create a hazard or damage the lighter. Keep out of reach of children. Always install so lighter can be pushed up toward mantle(s) when lighting, and pulled away from mantle(s) when lantern is lit.

**INSTALLATION INSTRUCTIONS:** On most Coleman lanterns the lighter can be affixed through one match hole without the attached bracket. In this case, loosen the set screw and remove the knob then loosen the nuts to remove the bracket. Install through the match hole that is farthest from

the lantern knob. It may be necessary to use two 1/4" flat washers (not included) to secure lighter through match hole (See Fig. 1). For installation on Model 200 and other older series lanterns, use the bracket by attaching it under the palmnut that is in the middle of the burner frame. (See Fig. 2.) The rest of the lighter assembly should still be routed through the match hole farthest away from the lantern knob. It may be necessary to slightly bend the bracket to an appropriate angle for the lighter to fit properly. Be sure that the flint container is rotated back towards the burner tube and away from the mantle.

**OPERATION INSTRUCTIONS:** The lighter is designed to be slid up towards the mantle for

lighting and down while using. Slide the lighter towards the mantle. Follow the lighting instructions included with the lantern before igniting the mantle. To light the mantle rotate lighter knob to produce sparks.

**CAUTION:** If the mantle fails to ignite immediately, turn fuel valve off and wait three minutes for accumulated fuel to dissipate before attempting to relight. After successful ignition, pull the lighter assembly back to the down position. A spare flint may be carried inside the lighter knob. Use standard replacement flints.